

Troubleshooting Details

Use this section in combination with the **oneRoam Service User Guide** provided if you are having trouble using your phone.

To change your Network Selection

1. Press **<Menu>**.
2. Scroll to **"Network Services"** press **<Select>**.
3. Scroll to **"Network Selection"** press **<Select>**.
4. Scroll to **"Manual"** press **<Select>**.
5. Scroll through available networks and select a network that you are not currently on, press **<OK>**.
6. Place a test call.

Tip: When placing a test call, call Roadpost and avoid airtime charges. Dial +1.905.272.5665 – always a free call from your Roadpost phone.

Special Instructions for your SAMSUNG SGH-X480



Powering On Your Phone

Press and hold <0> to turn the phone on and off.

Answering Calls

To answer an incoming call, flip open your phone.

The <+> Sign

The <+> sign is obtained by pressing and holding <0> on your Samsung SGH-X480. This symbol is required when dialing internationally, and in a few other instances referred to in the **oneRoam Service User Guide**.

Voicemail Access

Press and hold <1> to access your voicemail.

Changing Band Frequency


Use 900/1800 for most of Europe, Asia and Africa. Use 1900 for North America, most of South America and the Caribbean.

1. Press <Menu>.
2. Scroll to **"Network Services"**, press <Select>.
3. Scroll to **"Band Selection"**, press <Select>.
4. Select desired band frequency, press <OK>.


Text Messaging Instructions

You can send and receive text messages on your Samsung SGH-X480 phone. Please review your **oneRoam Service User Guide** for general instructions, detailed examples and information on your Text Messaging address.

Retrieving Text Messages

1. Press .
2. Select **"Inbox"** and scroll to read through your messages.
3. Use arrows and/or follow prompts to view, delete, and save messages.

Sending Text Messages to another cellular phone

1. Press .
2. Scroll to **"Messages"**, press <Select>.
3. Select **"Create"**, press <Select>.
4. Type your message using the keypad, press <Options>.
5. Select <Send Only>, press <Select>.
4. When prompted for a destination number, enter the phone number you are sending your message to, press <OK>.

Example: See oneRoam Service User Guide.